


YOUR ENTROVIEW PLUS VIDEO HANDSET USER GUIDE

1




The visitor presses the button for your flat number or dials your number on the main entrance panel

2




Your video handset will ring and the video monitor will display an image of the caller. If the call is not answered the system will reset to allow other calls.

3




Pick up your handset if you wish to speak.

4




1. Timed privacy button. This glows red when on. See no 7 for more info.
 2. Button not used.
 3. Door open button. Opens main entrance door and allows the caller to enter. Glows green when door is open. Wait 10 secs before pressing "door open" after lifting handset.
 4. You can adjust the call tone volume by sliding this switch. Push the switch once = low, twice = medium, three times = high.

5




If you press the "door open" button the main entrance panel will beep. Your visitor can now enter.

6




Please ask your visitor to ensure the door closes behind them. Replace your handset now.

7




If you do not want to be disturbed press the "privacy" button once. The red light will come on. Please note: you will not receive any calls for 8 hours when the red light is on. If you wish to receive calls before the 8 hour time-out press the "privacy" button again and the red light will go off.

8



Remember: it is up to you to control who comes into the building. Only let people in if you are sure of their identity. If you do not wish to speak or let them in simply replace the handset.

9



For your entry into the building place your token to the reader and open the door.

10



For your exit from the building push the exit button and open the door.