


LIFT CONTROL USER GUIDE

1




The visitor presses the button for your flat number or dials your number on the lift entrance panel

2




Your video handset will ring and the video monitor will display an image of the caller. If the call is not answered the system will reset to allow other calls.

3



Pick up the handset to answer the call if you have an EV5, or press the pick up button if you have an EV6.

4




Door open

Door open


To let the visitor gain access, press the door open button.

5




Explain to the visitor that they now need to press the lift call button. The lift will be selected and arrive at the ground floor. The door will automatically open and allow the caller to enter the lift.

6




Once in the lift the visitor needs to select the appropriate floor button.

7




Remember: it is up to you to control who comes into the lift. Only let people in if you are sure of their identity.

8



For resident entry into the lift place your token to the reader and press the lift call button, the lift will be called and the lift door will open.

9



Press the required floor button within the lift and you will travel to your floor.

10



If there is a basement or roof terrace/garden, where only residents require access, a reader will be fitted within the lift. Present your fob to the reader and then press the floor button you wish to travel to. If you have permission to access these floors, the lift will travel to the desired floor.